

# Care oil matrix

## for natural oiled surfaces from Bauwerk Parkett

	Oak Nature	Oak black limed	Oak slightly smoked	Oak Nuvola	Oak Roccia	Oak Avorio	Oak Farina	Oak smoked Farina	Oak Avena	Oak Caffelatte	Oak Creta	Oak Fango used-look	Oak slightly smoked Canneto	Oak Sasso	Oak Silver	Oak Deserto used-look	Oak slightly smoked Cacao	Oak Ambra	Oak Fumo	Oak Gold	Oak Mandorla	Oak Tabacco used-look	Oak slightly smoked Terra	Oak smoked Lava	Oak smoked	Acacia steamed Nature	Cherry American Nature	Walnut American Nature	Oak Caffè	Oak Caramello	Oak Fulvo
Colourless	●	●	●	●	●																										
White						●	●	●																							
Beige									●	●	●	●	●																		
Grey														●	●																
Light brown																●	●	●	●												
Golden brown																				●	●	●	●	●							
Brown																									●	●	●	●	●	●	●
Black																								●	●	●	●	●	●	●	●

● available as Care oil and Care oil Plus ● available as Care oil ● Alternative: colours more intense than brown

Alternatively you can use the solvent-free Care Oil Eco. Use Care Oil Eco white for Farina surfaces and colourless Care oil for all other surfaces.

A simple test can show whether or not natural-oiled parquet is sufficiently protected: Pour some water onto the surface. If the water forms compact droplets, the surface in that area is sufficiently saturated with oil.

### Oil saturation test

