

PARQUET IN THE BATHROOM

April 2017

Natural wooden parquet brings a pleasant warmth to your bathroom



Parquet: Bauwerk Studiopark, Oak smoked

Generate a new feeling of well-being! Bathrooms designed in pleasant natural wood colours always feel cosy and warm. If walls and floors are made from real wood, the perceived room temperature is one to two degrees above the actual temperature.

To make your lovely wooden barefoot floor in the bathroom last a long time, please take note of the following points:

- › *Type of wood:* Hardwoods, for instance oak, are the most suitable since they experience little shrinkage or swelling in humid conditions.
- › *Installation and initial care:* The floor should be installed fully bonded by an installation expert who should also take over the initial care of the floor.
- › *Airing:* Ensure sufficient airing of the room.
- › *Puddles:* Swiftly mop up any puddles after showering or bathing.

The right parquet care

Swiftly remove spots and puddles and wipe the floor dry. Always wipe the floor with a humid mop as too much water could damage the wood. Avoid aggressive cleaning agents. Suitable parquet care products are available at our online shop.

In the case of oiled parquet floors, annual or bi-annual re-oiling (depending on wear and tear) will preserve the beauty of your bathroom parquet for many years.

Further information is available at: www.bauwerk-parkett.com